

SPARK ADVANCE REMOVAL TOOL

Bill Rogers

www.isettadoc.com

This tool is used to remove the spark advance unit from the armature. It is very difficult to remove the advance unit without this tool. It can be made from a 17 mm by 30 mm long bolt with 1.0mm pitch threads. The bottom of the bolt should be tapered to prevent damage to the armature threads.

This tool may be purchase from several sources. Some are as follows:

Werner Schwark:

Email: lsettas@bellsouth.net

Dan

Web site: www.cycleworks.net

Email: dan@cycleworks.net

This photo shows the tool being used to remove the spark advance unit from the armature. Simply, screw the threaded end into the Spark advance unit until it bottoms out on the armature, then continue turning until it "pops" off of the armature.

